

Operation manual

1. Please download operate apps "iCsee" for camera as the below instruction.

A. Andriod Phone. Go to your google playstore to search "iCsee" to download

B. Apple Phone, Go to your app store to search "iCsee" to download.

C. Or scan the QR code directly to download the apps



iCSee


2. Please power on the camera. Then you will hear "System starting up. waiting to be configured"

Device Network Configuration

1. User Login (Figure 1)

A. Sign Up to Login

B. Use "local login" for quick login (Not Suggested! This login will not get any alert or push message)




Click "sign up" and input the corresponding information.

Click the "Local Login"

(Figure 1)

2. Click "+" to add the camera (Figure 2)

3. Click "Set up my device to Wi-Fi" (Figure 3)




(Figure 2)

(Figure 3)

4. Go with "Next Step" to setup your WIFI (Figure 4)

5. Filled with your wifi name and password. Then "confirm" (Figure 5)



Click the "Next Step"

(Figure 4)

(Figure 5)

6. Go with Device Searching to connecting with camera (Figure 6)

Attention: Please make sure the camera is close to the phone to be connected

7. During the connection, then the camera will say "Connecting, please waiting" (Figure 7)




(Figure 6)

(Figure 7)

8. After hearing "Connected successfully" Then set password for your camera (Figure 8)

9. Setup the Name for your camera (Figure 9)



(Figure 8)


(Figure 9)

10. Then you could view your camera on your phone View / operate your camera (Figure 10)

A. Alarm/Message Alert Setup (Figure 11)

1. Please go the setting (See figure)

2. Go to the "Alarm setting"



Share: You could invited people to add the camera And share the video

(Figure 10)

(Figure 11)


B. Alarm setting (Figure 12)

1. Open Alarm

2. Choose: Alarm Action way. Photo and video taken, or Deving beep


3. Alarm Push. You will get a alert Push.

4. You could choose Message Ignore or Not.




(Figure 12)

C. Message: If Alarm Push have been setup as the above. Then alert message will be sent when any motion detected, You could see all push message here with details (Figure 13)



(Figure 13)

11. Type it to view the video right now (Figure 14)




You could press it to talk with the one

Attention: You couldn't hear the audio when you talk After talk you could hear the audio as usual

(Figure 14)

1. Factory Reset: After press the reset button, then you will hear "Rest factory waiting, please don't power off"



You could press it to talk with the one

Attention: You couldn't hear the audio when you talk After talk you could hear the audio as usual

(Figure 14)

2. "Offline" Mean (A) Check Power: Low/No power for the doorbell (B) Check WIFI: Bad WIFI connection (C) Camera have been reset



You could press it to talk with the one


Attention: You couldn't hear the audio when you talk After talk you could hear the audio as usual

(Figure 14)

How to insert TF card 1. Please unscrew the speaker cover of the camera. See the below picture.



2. Turn off the cover, then you will find the SD card slot. If it is covered by cable, please take away the cable to insert the SD card.



NewPal After Sales Support
Email: Support@newpal.shop
www.newpal.shop