

## Main Menu

>Format	PAL↵
Video Mode	1080P@25↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Day/Night	Auto↵
Language	English
Advanced	↵
Default	
Exit	

## Backlight Mode

>BLC

On

Return

## Backlight Mode

>WDR 3

Return

## Backlight Mode

>HLC 3

Return

## Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Gamma	7
2DNR	7
Return	

## Exposure

>Exposure Mode Auto↵

Exposure Level 7

Anti-flicker Outdoor

Return

## Auto Exposure

>Gain Max Limit 10

Gain Min Limit 0

Return

Low Noise

>Gain Max Limit 10

Return



## Anti-smear

>Shutter Max 40ms

Return

## Manual Exposure

>Shutter 1/25

Gain Max Limit 10

Gain Min Limit 0

Return

## WB Manual

>Blue Gain      50

Red Gain      50

Return

## Day/Night

>Day/Night	7
Night/Day	17
Waiting Time	2
Return	

## Advanced

>Camera Name	Off
Mirror	↵
Smart IR	Auto↵
Anti-overexp	2
Voltage Prompt	On↵
Privacy Mask	Off
Coaxial 485	↵
System Info	↵
Video Type	CVI↵
Return	

## Camera Name

>Name ↵

Location ↵

Return

Camera Name

00000000

—

## Mirror

>H-Mirror      Off

V-Mirror      Off

Return



## Smart IR

>Level 7

Return

## Voltage Prompt

>Alarm Upload On

Return

## Privacy Mask

>Area Select      0  
  Display          On  
  Area Setting     Location↵  
  Default  
  Return

Coaxial 485

>Address 1

Application

Return

## System Info

Version No. 1.000.0000.5.R

>Return

> **Confirm**   **Cancel**