

Main Menu

>Format	PAL↵
Video Mode	1080P@25↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Day/Night	Auto↵
Language	English
Advanced	↵
Default	
Exit	

Backlight Mode

>BLC

On

Return

Backlight Mode

>WDR 3
Return

Backlight Mode

>HLC 3
Return

Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Sharp Suppress	7
Chroma Suppress	7
Gamma	7
2DNR	7
3DNR	7
Return	

Exposure

>Exposure Mode	Auto
Exposure Level	7
Anti-flicker	Outdoor
Return	

Auto Exposure

>Gain Max Limit	12
Gain Min Limit	0
Return	

Low Noise

>Gain Max Limit 12
Return

Anti-smear

>Shutter Max 40ms
Return

Manual Exposure

>Shutter	1/25
Gain Max Limit	12
Gain Min Limit	0
Return	

WB Manual

>Blue Gain	50
Red Gain	50
Return	

Day/Night

>Day/Night	6
Night/Day	12
Waiting Time	2
Return	

Advanced

>Camera Name	Off
Mirror	↓
Audio Mode	Built-in Audio↓
Smart IR	Auto↓
Voltage Prompt	On↓
Privacy Mask	Off
D-Zoom	1
Defog	Off
Next Page	↓
Return	

Advanced

>System Info ↓
 OSD Auto Save & Exit On
 Page Up ↓
 Return

Camera Name

>Name ↵
Location ↵
Return

Mirror

>H-Mirror	Off
V-Mirror	Off
Return	

Audio Mode

>Volume
Return

Medium

Smart IR

>Level 5
Return

Voltage Prompt

>Alarm Upload On
Return

Privacy Mask

Area Select	0
>Display	Off
Area Setting	Location↓
Default	
Return	

Defog

>Mode
Level
Return

Auto
Medium

System Info

Version No.

V1.000.000001.1.R

>Return