

Main Menu

>Format	PAL↵
Video Mode	4K↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Day/Night	Auto↵
Language	English
Advanced	↵
Default	
Exit	

Backlight Mode

>BLC

On

Return

Backlight Mode

>WDR

3

Return

Backlight Mode

>HLC

3

Return

Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Sharp Suppress	7
Chroma Suppress	7
Gamma	7
2DNR	7
3DNR	7
Return	

Exposure

>Exposure Mode	Auto↵
Exposure Level	7
Anti-flicker	Outdoor
Return	

Auto Exposure

>Gain Max Limit	12
Gain Min Limit	0
Return	

Low Noise

>Gain Max Limit 12
Return

Anti-smear

>Shutter Max
Return

40ms

Manual Exposure

>Shutter	1/25
Gain Max Limit	12
Gain Min Limit	0
Return	

WB Manual

>Blue Gain	50
Red Gain	50
Return	

Day/Night

>Day/Night	6
Night/Day	12
Waiting Time	2
Return	

Advanced

>Camera Name	Off
Mirror	↓
Audio Mode	Built-in Audio↓
Smart IR	Auto↓
Voltage Prompt	On↓
Privacy Mask	Off
D-Zoom	1
Defog	Off
Next Page	↓
Return	


Camera Name

>Name ↵
Location ↵
Return

Camera Name

00000000

—



Mirror

>H-Mirror	Off
V-Mirror	Off
Return	

Audio Mode

>Volume
Return

Medium

Smart IR

>Level
Return

5

Voltage Prompt

>Alarm Upload 0n

Return

Privacy Mask

>Area Select	0
Display	On
Area Setting	Location↵
Default	
Return	

Defog

>Mode

Level

Return

Auto

Medium

Advanced

>System Info ↓
 OSD Auto Save & Exit On
 Page Up ↓
 Return

System Info

Version No.

V1.000.0000002.1.R

>Return

Save

>Yes

No

Cancel